



**Parts List shown overleaf**



**Scout Part List –MS008 / MS009**  
**(Issued 10-16)**

No.	Code	Description
1	S12-069-00100	Speed Dial, Scout
2	S02-069-00100	T Type Handlebar, Scout
3	S08-069-00400	Upper Tiller Pod, Scout
4	S08-069-00600	Lower Tiller Pod, Scout
5	S02-069-00300	Tiller Adjustment, Scout
6	S08-069-00100	Front Shroud, Scout
7	S08-069-00300	Rear Shroud, Scout
8	S01-069-00100	Frame, Rear, Scout
9	S01-069-00300	Frame, Front, Scout
10	S03-069-00100	L Type Steering Axle, Scout
11	S09-069-00100	Motor & Transaxle Assy, Scout
12	SCOUTBP12	12ah Battery Pack, Scout * <sub>1</sub>
13	SCOUTBP20	20ah Battery Pack, Scout * <sub>1</sub>
14	S02-060-00200	Regular Bearing Ball Set
15	S03-069-00200	Front Fork, Scout
16	S03-060-00200	Track rod Assy, Scout/Kite

No.	Code	Description
17	S05-060-00200	Front Wheel, 8" Black PU Tyre
18	S01-069-00500	Holder Assembly, Scout
19	S07-060-00200	Seat Assembly, Kite/Scout
19	S07-035-00300	Seat Ass'y (MS009 ONLY)
20	S07-069-00100	Seat Post, Scout
21	S08-069-00200	Footrest Shroud, Scout
22	C07-027-00601	Armrest, Left, Scout
23	C07-027-00701	Armrest, Right, Scout
24	C10-060-00100	Curtis 1212 Controller 45A
25	S06-060-00100	Rear Wheel, 8" Black PU Tyre
26	S18-069-00100	Wire Harness Assy, Scout
27	S08-069-00700	Battery Pedestal, Scout
28	S08-069-00800	Front Bumper, Scout
29	S02-069-00400	Tiller Lock, Scout
30	S08-069-00918	Scout Colour Panels, Red
30	S08-069-00954	Scout Colour Panels, Blue
31	S08-069-01200	Battery Pack Lock, Scout

**Separate Components Available:**

**From the Motor & Transaxle Ass'y:**

C09-050-00100 (Transaxle, Kite/Scout)  
C09-069-00200 (EM Brake, Scout)  
C09-069-00401 (Motor, 4700RPM, 270W)

**Batteries**

12V12AH (12ah 12V VRLA Battery)  
12V20AH (20ah 12V VRLA Battery)  
C11-033-00101 (Battery Gauge)  
C11-023-00200 (Fixing plate, Battery Gauge)

**From the Chassis**

S08-069-01100 (Chassis Splitting Handle, Scout)  
S12-034-00100 (Rear Power Connector, Scout)  
S12-034-00200 (Front Power Connector, Scout)

**Seat Covers**

C07-060-00900 (Seat base cover)  
C07-060-01000 (Seat back cover)

**From the Tiller Pod**

C18-060-00700 (Key Switch, Scout)  
C18-050-00600 (Key, Scout)  
C12-060-00100 (Speed Dial, Scout)

**Basket**

C23-067-00100 (Plastic Basket, Scout)  
C26-009-01700 (Basket Holder, Lower, Scout)  
C26-009-01601 ( Basket Holder, Upper, Scout)

**Charger**

C12-071-00400 (Charger, Prism/Scout without mains cable)  
C12-071-01000 ( mains cable 2 pin )

**Armrest**

M4300020000 (Arm Rest Knob)